



## **Why does my ABS light come on when I hit my brakes?**

Constant power is not being supplied to the ABS through the blue wire on your 7 way connector so every time you hit your brakes, the ABS system has to pull power off of your red wire (brake wire) and turns the system on and then it goes off when you let off the brakes. To correct this, make sure blue auxiliary wire is hot to trailer.

See Your Local TimpTe Branch For All Your Parts And Service Needs!

© 2011 TimpTe Inc.

[www.timpTe.com](http://www.timpTe.com)