



## How do I manually operate my electric tarp if my motor should fail?

Remove the bolt that connects the motor to the tarp pipe, install crank handle to the rear tarp pipe at back end of trailer.

See Your Local TimpTe Branch For All Your Parts And Service Needs!

© 2011 TimpTe Inc.

[www.timpTe.com](http://www.timpTe.com)